



## SealGreen Poly StepGuard and Poly StepGuard with Anti-Skid



Size	Makes	Covers
Pint	Pint	40 - 50 sqft
Quart	Quart	85 - 100 sqft
Gallon	Gallon	350 - 400 sqft
5 Gallons	5 Gallons	1,750 – 2,000 sqft

### Application –

- PolyStepGuard may be applied by brush, roller (short nap), or low-pressure airless sprayer. Stir or shake the container vigorously to mix well prior to use.
- The targeted surface to be clear of dirt, debris, and oil or grease before application.
- One coat is usually sufficient, however if a second coat is required, allow first coat to dry thoroughly for an hour or more depending on ambient temperature.
- Allow 24 hours or more for full cure before subjecting the surface to heavy traffic.
- Avoid heavy build up or puddling during application.